




Recommended Minimum Spare Parts List 25PF NG Fusion Furnace

<i>Image</i>	<i>Description</i>	<i>Suggested Stock Qty.</i>	<i>Part Number</i>
	Air Pressure Switch DG10-3 1-10mbar	1	RF341APS
	Blower Assembly Aerotech 4 Pole (220 – 240V) (NG & Oil)	1	PFAERO4P
	Burner Assembly for 25PF Natural Gas/Oil Furnace	1	PF325PFA
	Burner Controller LFL1.1635	2	RF336LFL
	Ceramic Anchor 3" (Complete Assembly) (Set of 8)	1	PC128008
	Foot Pedal (Festo)	1	RF357FFP
	Furnace Tile, 700 x 610 x 22mm (Suit 25 & 50PF Furnace)	10	LFT70022
	Gas Pilot Burner (Natural Gas) 56 Air 9-64 (W)	1	PF339GPB
	Gas Pressure Switch(Low) DG50N	1	RF363PSW
	Ignition Lead (Copper Cord) (Per metre)	5	RF217000
	Ignition Transformer, TC1LVCA	1	RTC1L926







Recommended Minimum Spare Parts List 25PF NG Fusion Furnace

<i>Image</i>	<i>Description</i>	<i>Suggested Stock Qty.</i>	<i>Part Number</i>
	Superwool Ceramic Fibre Blanket 25mm 7.6m x 610mm	1	JB128025
	Solenoid Valve, Pilot (NG) DIN Plug	1	RF210FF7
	Spark Plug (Igniter) (NG & Oil)	2	RF338SPI
	Speed Controller ABB 0.75KW	1	RF37775C
	Temperature Controller RKC100CB	1	RF381RKC
	Thermocouple Element, Type K. 310mm	6	PF201FF1
	Thermocouple Head (1/2")	1	RJB35TCH
	Thermocouple Sheath (Inconel)	4	PF203FF2
	Toggle Switch On/Off, High/Low	1	RA93A401
	U.V. Amp Meter	1	RF373UVA

Recommended Minimum Spare Parts List 25PF NG Fusion Furnace

<i>Image</i>	<i>Description</i>	<i>Suggested Stock Qty.</i>	<i>Part Number</i>
	U.V. Cell, (Flame Detector) QRA.2	4	RF204FF3
	Valve Train, Natural Gas 240V	1	RF352NGV
	Parts Packaging & ISPM15 Certified Wood Crate	1	ZZPCRATE



Recommended Minimum Spare Parts List 25PF NG Fusion Furnace CANADA

<i>Image</i>	<i>Description</i>	<i>Suggested Stock Qty.</i>	<i>Part Number</i>
	Air Pressure Switch Honeywell C6097A1004	1	RFAPSHON
	Aero-Tech 110v Baldur Motor Comb Air Fan	1	RFBALDMR
	Burner Assembly for 25PF Natural Gas/Oil Furnace	1	PF325PFA
	Burner Controller, LFL 1.635 110 Volt	2	RF110LFL
	Ceramic Anchor 3" (Complete Assembly) (Set of 8)	1	PC128008
	Foot Pedal (Festo)	1	RF357FFP
	Furnace Tile, 700 x 610 x 22mm (Suit 25 & 50PF Furnace)	10	LFT70022
	Gas Pilot Burner (Natural Gas) 56 Air 9-64 (W)	1	PF339GPB
	Low Gas Pressure Switch Honeywell C6097A1012 Man Reset 3-21"WC	1	RFLPS97A
	Ignition Lead (Copper Cord) (Per metre)	5	RF217000

Recommended Minimum Spare Parts List 25PF NG Fusion Furnace CANADA

<i>Image</i>	<i>Description</i>	<i>Suggested Stock Qty.</i>	<i>Part Number</i>
	Ignition Transformer TZI7 5-20/33R	1	RFITTZ17
	Superwool Ceramic Fibre Blanket 25mm 7.6m x 610mm	1	JB128025
	Pilot Solenoid Valve 110v Krom Schroder VAS110	1	RFVAS110
	Spark Plug (Igniter) (NG & Oil)	2	RF338SPI
	Temperature Controller RKC100CB	1	RF381RKC
	Temperature Controller RKC O/T SA100 DIN Rail Mount	1	RF382RKC
	Thermocouple Element, Type K. 310mm	6	PF201FF1
	Thermocouple Head (1/2")	1	RJB35TCH
	Thermocouple Sheath (Inconel)	4	PF203FF2
	Toggle Switch On/Off, High/Low	1	RA93A401

Recommended Minimum Spare Parts List 25PF NG Fusion Furnace CANADA

<i>Image</i>	<i>Description</i>	<i>Suggested Stock Qty.</i>	<i>Part Number</i>
	U.V. Amp Meter	1	RF373UVA
	U.V. Cell, (Flame Detector) QRA.2	4	RF204FF3
	Valve Train, Natural Gas 110 Volt	1	RF110NGV
	Parts Packaging & ISPM15 Certified Wood Crate	1	ZZPCRATE